

Specification

| | |
|----------------------|--------------------------------|
| Model | TR-D4S5-noPoE |
| Image sensor | 1/2.7" CMOS 4MP |
| Resolution | 4MP (2688x1520) |
| Frame rate | 4MP@15fps |
| Day/Night Mode | Mechanical ICR |
| Sensitivity | 0.005Lux (F1.8) / 0Lux (IR on) |
| IR range | up to 25 m |
| Focal length (mm) | 3.6 |
| WDR | D-WDR |
| Video compression | H.264 / H.265 |
| Bitrate | 8Mbps |
| Audio | None |
| Power supply | 12V DC |
| Power consumption | 6.4 W |
| Dimensions (mm) | Ø106 x 73.5 |
| Net weight (g) | 370 |
| Protection level | IP66 |
| Operating conditions | -40°C ... +60°C |

Camera Package

| | |
|--------------|------|
| IP camera | 1 pc |
| User manual | 1 pc |
| Mounting kit | 1 pc |


Technical support

www: helpdesk.trassir.com
mail: helpdesk@trassir.com

TR-D4S5-noPoE

4MP Sphere IP camera

TRASSIR



Data _____ Stamp _____

Here is the confirmation form for warranty assurance

Note: read user manual before using
Website: www.trassir.com
For any inquiry: info@trassir.com

Introduction

Congratulations with purchasing of IP camera TR-D4S5-noPoE.

Please read User Manual before using a camera.

Key features


- Support codec H.265
- Wide Dynamic Range (D-WDR)
- Digital Noise Reduction (3D-DNR)
- Automatic Day/Night Mode
- Mechanical IR cut filter
- Power supply 12V DC

Connecting

To get started with TRASSIR IP camera you are required to have a PC connected to the local network with Windows installed and Internet Explorer version 8 or higher.

1. Connect IP camera to the network.
2. Connect 12V AC adapter to power jack.

Dimensions



Notes:

Power supply should meet the requirements: output voltage, current, polarities and working temperature. Pay attention that you have lightning conductor while using IP camera during a storm or plug off power connector.

Pay attention to temperature requirements of IP camera. Do not use the camera in extremely hot or cold temperatures (see the specifications for operating conditions).

Do not expose the camera to heaters.

Do not aim the camera at the sun or at the strong light. It causes damages to the camera.

Manual setting of network parameters.

IP camera and PC should be in one local network to connect to each other. In this case IP address of a camera, PC or any other devices shouldn't match each other.

IP camera has the following default settings:

- IP address: 192.168.1.188
- Subnet mask: 255.255.0.0
- Gateway: 192.168.1.1
- HTTP-port: 80
- username: admin
- password: admin

Example of network settings for PC to connect to IP-camera:

- IP address: 192.168.1.10;
- Subnet mask: 255.255.0.0.

There are 3 options to set up your camera:

1. Change IP address of a camera manually.
Start your browser, connect to IP camera and enter your username and password. Choose appropriate menu item and change network settings of IP camera.
2. Set IP address of a camera using fast configuration utility which could be downloaded from www.trassir.com.
3. Change IP camera settings using TRASSIR professional software.

Find detailed instruction on camera settings in user manual which could be downloaded from our website www.trassir.com.